

Acupressure Node Holder

The Acupressure Node Holder will keep your Acupressure Nodes neatly stored and easily accessible on your inversion table!

Assembly

Figure 1: Attach the Acupressure Nodes by aligning their Base with the Holder clips. Push firmly until you hear or feel a click. **NOTE:** You may need to slightly unscrew the black backing on the Node to fit in the clip.

Figures 2-4: Choose from three placement options on the Main Shaft Housing under the Table Bed. Make sure the Nodes are accessible and don't interfere with the inversion table functionality.

Figure 4: Expose the adhesive by carefully peeling the protective backing off the three (3) adhesive strips. Press the Node Holder firmly onto your chosen spot on the Main Shaft Housing, ensuring even pressure on all adhesive spots. Hold for a few seconds to allow the adhesive to bond.

Refer to your Inversion Table Assembly Instructions and User Guide for more information on using the Acupressure Nodes with your Teeter.




Figure 1



Figures 2-4

